

Anasphere Plus

A complete booklet of Directions for Use Label for Anasphere Plus will be included in each box of purchased product or on Anabec's web-site; www.anabec.com, under products and supplies tab, Anasphere Plus and go to Product Info on the lower right hand side and click in Master Label.



IMPORTANT: Anasphere Plus is NOT FOR USE ON CPVC Piping and Fittings

Anasphere Plus is an EPA registered hospital grade disinfectant, detergent, fungicide, bactericide, virucide and mildewstat. Anasphere Plus offers the best science the world has to offer. Anasphere Plus is effective against most pathogens currently affecting the world. Anasphere Plus has over 140 kill claims, including but not limited to; Hepatitis B & C virus, Herpes Simplex type 1 & 2 virus, HIV-1 (AIDS virus), MRSA, Influenza (All Strains), Measles virus, Noro virus and many more. Anasphere Plus can be used as a stand-alone product or can be applied after cleaning the surface with the Advanced Cleaning Solution Plus. Anasphere Plus is a concentrate and is mixed according to the appropriate dilution rates listed in the Master Label for the specific cleaning or disinfecting project. Anasphere Plus may be used on washable hard non-porous surfaces.

Anasphere Plus can be used in the following areas to name just a few; Water Damage Restoration, Smoke Damage Restoration, Disinfection/Fungicidal/*Virucidal*, Cleaning and Decontamination against HIV-1, HCV & HBV on Surfaces/Objects Soiled with Bloody/Body Fluids, General Deodorization, Mold & Mildew Control, Disinfect Toilet Bowls, Poultry (and Swine) Premise Sanitation Site Preparation, Farm Premise Disinfection, Veterinary Clinics/Animal Life Science Laboratory/Zoos/Pet Shop/Kennels/Breeding and grooming Establishment/Tack Shops Disinfection, Sanitizing Incubators and Hatchers, Commercial Florist Use, Laundry Additive (Residual Bacteriostatic and Residual Self Sanitizing Activity under Conditions of High Relative Humidity or Wet Contamination) Against Odor-Causing Bacteria for Institutional, Industrial and Hospital Use, Odors Caused by Dogs, Cats and Other Domestic Animals, Carpet Deodorizer Against Odor-Causing Bacteria, for Home, Institutional, Industrial and Hospital Use, Salon Barber Instruments and Tools Sanitizer, Shoe Bath Sanitizer and Food processing Plants.

1. **Precleaning:** To achieve the best results, Anabec recommends pre-cleaning heavily soiled surfaces with Anabec's Advanced Cleaning Solution Plus. Failure to pre-clean heavily soiled surfaces will diminish Anasphere Plus's effectiveness.
2. **Mixing:** Refer to the Anasphere Plus Master Label for specific application mixing concentrations. The Master Label is included with your purchase or can also be found on the Anabec web-site; www.anabec.com.

3. **Labeling:** For product control, secondary bottles of ready to use Anasphere Plus should be labeled with the contents but do not need a complete pesticide label. To remain in compliance with regulations, the ready to use mixture of Anasphere Plus cannot be distributed, sold, or left behind with a customer.
4. **Safety:** Anasphere Plus as a concentrate and is corrosive in the concentrated form. Anasphere Plus may cause skin and eye irritation. Anasphere Plus is harmful if swallowed. When mixing and applying Anasphere Plus, take precautions, such as; PPE (gloves, safety glasses, respiratory protection and disposable full body clothing) to avoid skin or eye contact. If spraying or fogging, respiratory protection is necessary to avoid breathing in the mist. Refer to both the product SDS and the Master Label for a complete list of hazard identifications and first aid measures. Consult with your corporate health and safety personnel for further guidance.
5. **Materials Compatibility:** Ensure sensitive building materials, furnishings and any other sensitive materials are either protected or verified compatible with the Anabec products by testing small inconspicuous areas and checking with material manufacturers. Items of concern include certain types of plastics; including CPVC piping and fittings, electronics and non-colorfast fabrics.
6. **Airless Sprayer Application:** Spray a light coat of Anasphere Plus to the walls, ceilings, floors and inanimate objects using an airless sprayer until all of surfaces are thoroughly wet. The recommended tip size for the airless sprayer is .011. Refer to the Master Label for a complete list of instructions for use of Anasphere Plus including the required time that the surfaces must remain wet.
7. **Fogging Application:** When using a fogger, contain the space to be fogged, fog the space with Anasphere Plus until all surfaces are thoroughly wetted. Refer to the Master Label for a complete list of instructions for use of Anasphere Plus including the required time that the surfaces must remain wet. Allow 2 hours for the fog to dissipate before entering the space without PPE. Thermal Foggers **cannot** be used with Anasphere Plus. When using a commercial fogger an Electric Ultra-Low –Volume (ULV) fogger should be used.
8. **Clean-up:** Equipment clean up requires clean water only.

Refer to the full product Master Label for a complete list of the EPA approved applications and instructions for Anasphere Plus.